

Brannan instruction sheet

MAX MIN THERMOMETER HYGROMETER

Specification

- **Range:** -10 to 50°C (14 to 122°F), 10% to 90% RH
- **Resolution:** 0.1°C / 0.1°F
- **Temperature accuracy:** +/- 1°C (0 to 40°C), otherwise +/- 2°C
- **Humidity accuracy:** +/- 5% (30 to 60%RH), otherwise +/- 8%
- **Display:** LCD
- **Reading update:** every 10 seconds
- **Battery:** 1pcs AAA battery, 1.5V
- **Dimensions:** 94 x 74 x 19.5mm

Operating Instructions:

POWER ON:

The instrument will power on when the batteries are installed.

°C / °F:

Press the °C/°F button on the back of the instrument to alternate between Celsius and Fahrenheit.

CLEAR MEMORY:



Hold the °C/°F for 3 seconds to reset the Max/Min temperature and humidity memory. After power on or manual reset, the Max/Min memory will automatically clear after 24 hours.

HUMIDITY COMFORT SYMBOLS:

When the humidity is lower than 40%, "DRY" will be displayed (fig.1).

When the humidity is between 40% and 70% and the temperature is between 18°C and 25°C, "OK" will be displayed (fig.2).

When the humidity exceeds 70%, "WET" will be displayed (fig.3).



POWER OFF:

When the instrument is not in use, remove the battery to power off.

brannan.co.uk

Manufacturer: S. Brannan & Sons Ltd, Leconfield Industrial Estate, Cleator Moor, Cumbria, UK, CA25 5QE (sales@brannan.co.uk)
EU Authorised Representative: Comply Express Unipessoal Limitada, Startup Madeira EV141, Campus da Penteada, Funchal 9020-105, Madeira, Portugal. (info@complyexpress.com)

Measurement for life.

