

Triple Display Digital Timer (28/214/0)

Basic Settings

To switch between "Time/Count Up" and "Count Down" modes, press "CLOCK/TIMER" button.

1. Under "Time/Count Up" mode, press "CLOCK/TIMER" for 2 seconds until the screen flashes to enter time setting menu.
2. Press the "HR" button to increase hours value, the "MIN" button to increase minutes value and "SEC" button to increase seconds value.
3. Press the "CLOCK/TIMER" button to confirm the new setting.

Count Up Timer - 99 hours, 59 minutes and 59 seconds

1. Under "Time/Count Up" mode, press "START/STOP" to start count up. Press "START/STOP" again to pause and again to continue count up.
2. When timer paused, press "CLEAR" to reset timer to zero.

Countdown Timer - 3 sets x 99 hours, 59 minutes and 59 seconds

Press "CLOCK/TIMER" button to enter "Count Down" mode.

Countdown settings

The timer allows 3 sets of countdown timings - T1 to T3. Using T1 as an example:

1. Press "T1" button for 2 seconds until "T1" starts flashing.
2. Press the "HR" button to increase hours value, the "MIN" button to increase minutes value and "SEC" button to increase seconds value.
3. Press "T1" button to confirm the new settings.
4. Repeat the above steps for T2 and T3 if required.
5. Press "CLEAR" to reset timer to zero.

Starting Countdown

1. Press "T1" button to start the T1 countdown, the "T2" button to start the T2 countdown and the "T3" button to start the T3 countdown.
2. Press "T1", "T2" or "T3" button again to pause timer. Press again to continue with countdown. "TIMER1", "TIMER2" or "TIMER3" message will appear in Time/CountUp mode while it is counting down.
3. Press "CLEAR" to reset a timer or to reset all 3 timer settings back to zero when the timer is in the pause status.
4. Press "START/STOP" to recall the last setting. When the timer is reset to zero, a "MEMORY" message will appear on its corresponding screen.

Stopping a Countdown

1. Once it reaches the set time, a "TIME'S UP" message will appear. The screen will flash, continue to count up and will beep for 1 minute.
2. When timer reaches set time, press "T1", "T2" or "T3" or "START/STOP" to stop the alarm and timer. Press "CLEAR" to reset timer to zero. Timer must be at zero to enter new timing settings.

*The "TIME'S UP" and "TIMER1" ("TIMER2", "TIMER3") message will flash when in CLOCK/TIMER mode.

Battery

Replace batteries with LR44 x 2.

Please remove batteries if the timer will not be used for an extended period of time.

Keep batteries away from children.



Please dispose of electrical devices in accordance with local regulation

Manufacturer: S. Brannan & Sons Ltd. Leconfield Industrial Estate, Cleator Moor, Cumbria, UK, CA25 5QE (sales@brannan.co.uk)
EU Authorised Representative: Comply Express Unipessoal Limitada, Startup Madeira EV141, Campus da Penteada, Funchal 9020-105, Madeira, Portugal. (info@complyexpress.com)

www.brannan.co.uk