

Brannan instruction sheet

DIAL MAX MIN THERMOMETER & HUMIDITY METER

Product features:

- 100mm diameter gilt dial
- Red and blue max min temperature indicators
- Measures temperature and humidity
- Hanging hook

Product specification:

Thermometer range:	-20 to +50°C&F
Humidity range:	0 to 100%RH
Thermometer accuracy:	+/- 1°C between 0 and 30°C, otherwise +/- 2°C
Humidity accuracy:	+/- 5%RH between 40 and 80%RH, otherwise +/- 9%RH
Divisions:	1°C / 2%RH
CE/ROHS/WEEE:	N/A
Hazard information (SDS):	See brannan.co.uk for information
Product material:	ABS casing, aluminium rim and dial, SS 431 pointers, glass lens, brass indicator, bi-metal sensor
Product weight:	Gross: 118g Net: 86g
Product dimensions:	Gross: 108mm x 108mm x 45mm* Net: 100mm diameter x 40mm
Display box weight:	30g
Display box dimensions:	108mm x 108mm x 45mm

A simple instrument to record the highest and lowest temperatures, day and night.

The red pointer indicates the highest or maximum temperature reached since the instrument was last reset.

The blue pointer indicates the lowest or minimum temperature reached since the instrument was last reset.

The black pointer shows the actual temperature at the time of reading.

To reset the maximum and minimum pointers:

1. Turn the red pointer anticlockwise, using the larger nut, until it just touches the black pointer.
2. Turn the blue pointer clockwise, using the smaller nut, until it also just touches the black pointer.

Please note:

This dial is suitable for outdoor use but should be kept sheltered from direct sunlight and rain.