

Brannan instruction sheet

JUMBO MAX MIN THERMOMETER & HUMIDITY METER

Features:

- Temperature and humidity meter with clock
- Displays indoor or outdoor temperature (when probe attached) and indoor humidity
- Records maximum and minimum temperature and humidity
- Display Celsius or Fahrenheit scale
- 12 or 24 hour time display
- Display automatically changes from time to date every 5 seconds
- Stainless steel probe with 2m cable (replacement probe order reference: 12/421/1)
- Robust case with hanging hook and desk stand

Note: The **IN** reading relates to the sensor on the main unit

The **OUT** reading relates to the probe sensor reading

Product specifications

Temperature range:	Indoor: -10 to +50°C (+14 to +122°F) / Outdoor: -50 to +70°C (-58 to +158°F)
Humidity range:	20 to 90% RH
Ambient operating temp.:	Indoor: -10 to +50°C/F
Resolution:	0.1°C / 1%RH
Accuracy:	+/-1°C between -10 and 60°C, otherwise +/-2°C +/- 5%RH between 30 and 90%RH , otherwise +/-7%RH
Battery:	1pc x AAA included

Instructions:

1. Attach probe and position outdoors to enable outdoor temperature reading.
2. Remove tab from battery compartment and press **RESET**.*
3. Press **°C/F*** to switch temperature units between Celsius and Fahrenheit.
4. **Clock:**
To select 12 or 24 hour clock - hold **MODE** for 2 seconds, press **ADJ** to change from 12 to 24 hour clock.
Press **MODE** to cycle through time/date setting. Press **ADJ** to alter time/date settings.
5. **Alarm:**
When display shows time, press **MODE**, "AL" shows on display.
Press **ADJ** to select () for any alarm time set, or () for alarm set on the hour only, or () for both.
Press and hold **MODE** for 2 seconds, hour will flash. Press **ADJ** to set hour for alarm, then **MODE** and **ADJ** again to set minutes. When alarm sounds, press **MODE** to stop sound.
6. **MAX MIN**
Press **MEMORY** to show maximum values recorded.
Press **MEMORY** again to show minimum values recorded.
Press and hold **MEMORY** for 2 seconds to clear memory.

* **RESET** and **°C/°F** switch can be found at back of instrument, behind stand.
Insert non-metallic toothpick, etc, into required hole.

Note:

If abnormal display appears, press **RESET**.

Dispose of used meter and battery in accordance with local regulations.

Manufacturer: S. Brannan & Sons Ltd, Leconfield Industrial Estate, Cleator Moor, Cumbria, UK, CA25 5QE (sales@brannan.co.uk)
EU Authorised Representative: Comply Express Unipessoal Limitada, Startup Madeira EV141, Campus da Penteada, Funchal 9020-105, Madeira, Portugal. (info@complyexpress.com)