

# Brannan instruction sheet

## DIGITAL MAX MIN THERMOMETER



### Product features:

- Large digital thermometers in robust casing
- Shows minimum, maximum and current temperatures simultaneously
- Suitable for indoor or outdoor\* use
- Supplied with battery

### Product specification:

**Temperature range:** -10 to +50°C&F

**Resolution:** 0.1°C

**Accuracy:** +/-1°C

**Sampling rate:** Every 10 seconds

**Battery:** 1 x AA

**LCD dimensions:** 79mm x 60mm

**Dimensions:** 160mm x 78mm x 31mm

**Weight:** 58g (incl. battery)

### Instructions:

Remove protective film from LCD before use.

Open battery compartment cover and remove tab protecting battery.

The thermometer should be positioned away from direct sunlight, rainfall and draughts to ensure an accurate reading. (NB: This thermometer is not waterproof).

The minimum reading indicates how low the temperature has dropped since last reset.

The maximum reading indicates how high the temperature has risen since reset.

The current temperature is displayed in the centre of the LCD.



→ Maximum Temperature

→ Current Temperature

→ Minimum Temperature

To reset the readings, press the CLEAR button.

To switch Celsius to Fahrenheit, press C/F button.

**brannan.co.uk**

Manufacturer: S. Brannan & Sons Ltd, Leconfield Industrial Estate, Cleator Moor, Cumbria, UK, CA25 5QE (sales@brannan.co.uk)  
EU Authorised Representative: Comply Express Unipessoal Limitada, Startup Madeira EV141, Campus da Penteada, Funchal 9020-105, Madeira, Portugal. (info@complyexpress.com)

**Measurement for life.**

