

Waterproof Digital 'Classic' Maximum/Minimum Thermometer

Digital Max/Min Thermometers - FAQs

Where is the best place to position my digital max/min thermometer?

- Always position the thermometer out of direct sunlight to ensure accurate readings are displayed and to prolong the life of the product.
- Position the thermometer away from draughts to ensure an accurate reading is obtained.
- Position the thermometer away from direct rainfall to prolong the life of the product.

Why is my digital max/min thermometer reading higher than the actual temperature?

- This is likely due to the thermometer being positioned in direct sunlight. The sun's radiation causes the thermometer to read higher than the true temperature.
- Please ensure you keep your thermometer in the shade, away from direct sunlight.

I bought 2 digital max/min thermometers but they both give different readings?

- All thermometers have an accuracy tolerance, and therefore there may be slightly different readings between different thermometers.
- For example, the true temperature may be 20.2°C and the thermometer accuracy may be $\pm 1^\circ\text{C}$. THERMOMETER 1 may read 19.2°C and THERMOMETER 2 may read 21.2°C. Although the thermometers read 2.0°C apart, they are both still within the accuracy specification.

The digital max/min thermometer displays a different reading to my old thermometer?

- As above, although the thermometers display different readings, they may both still be within the manufacturer's accuracy specification.
- Different style thermometers also have different response rates. Please allow both thermometers to acclimatise, untouched, for at least 1 hour and then compare the readings.

The screen on my digital max/min thermometer has died?

- As with all electronic products, if the thermometer is positioned in direct sunlight, the screen will become faint and eventually die.
- The screen will also die if water and/or moisture enters the internals of the thermometer.

Water has entered my digital max/min thermometer. I thought it was 'waterproof'?

- This waterproof model is waterproof to IP66, meaning they are protected from high pressure water jets from any direction for a period of time.
- However, the product may not survive if fully submerged in water or subject to prolonged periods of very heavy rainfall.
- Position the thermometer away from direct rainfall to prolong the life of the product.

How can I remove the battery cover on my digital max/min thermometer?

- To ensure the products are waterproof, the battery cover includes a waterproof seal. Care needs to be taken to avoid damaging this seal. Partially unscrew the battery cover, then place the end of the screwdriver under the screw to carefully lever the cover out.

Manufacturer: S. Brannan & Sons Ltd, Leconfield Industrial Estate, Cleator Moor, Cumbria, UK, CA25 5QE (sales@brannan.co.uk)

EU Authorised Representative: Comply Express Unipessoal Limitada, Startup Madeira EV141, Campus da Penteada, Funchal 9020-105, Madeira, Portugal. (info@complyexpress.com)

Rev.5.2024