

Brannan instruction sheet



UK
CA

Water resistant and steam proof digital timer (28/215/0)

Product specifications:

Count range:	99 minutes, 59 seconds
Ingress protection:	IP64
Battery:	1pc x LR44 (included)
Timer dimensions:	91 x 79 x 25mm
LCD dimensions:	20 x 39mm
Net weight:	53g

Countdown timer

1. Press "MIN" and "SEC" to set desired timing period.
2. Press "START/STOP" button to begin timer.
3. Alarm will sound with time is up. Press "START/STOP" to stop alarm.

Stopwatch

1. Press "START/STOP" button to start timing.
2. Press "START/STOP" to stop.

To clear display

Press "MIN" and "SEC" together. Display will show "00.00".

To pause timer

At any time, press "START/STOP" button. Press "START/STOP" again to continue count.

Battery installation

1. Remove battery cover on back of timer by removing the 4 screws. Insert 1 x LR44 battery.
2. Replace cover then press "MIN" and "SEC" buttons together to clear timer.

Battery warning - Remove battery if timer will not be used for an extended period.

Keep battery away from children.

Care of your product

1. Avoid exposing timer to extreme temperature, water or severe shock.
2. Avoid contact with any corrosive materials such as alcohol or cleaning agents.

Caution: This timer is water resistant and not waterproof. Do not allow a stream of water to run directly over the timer.

Note: Ensure that the application surface and suction cup are clean prior to attaching your timer.



Please dispose of electrical devices in accordance with local regulation

brannan.co.uk

Rev.0.2021

Measurement for life.

