

Brannan instruction sheet

FOUR WAY TIMER & CLOCK

Please fully read the installation instructions before use.

Product features:

- Four timers in one compact unit
- Count up and down
- Complete with hanging hook, magnetic back and stand
- Large, easy to read display

Product specification:

Timer keeping:	Hour, minutes, seconds, AM/PM timer indicators (T1 to T4)
Timer count:	99 hours, 59 minutes, 12/24 hour clock
Accuracy:	+/- 30 seconds/month
Operating conditions:	0 to 40°C < 95%RH (non-condensing)
Battery:	2 x AAA (included)
LCD dimensions:	23mm x 55mm
Dimensions:	70mm x 88mm x 20mm
Weight:	86g (incl. battery)

Operating instructions:

1. To insert battery

Slide and open the battery door of the unit. Insert batteries, matching the "+" and "-" polarities.

2. Helpful hints on using the clock/timer

- Timing capacity: Timer channels time from 1 second to 99 hours, 59 minutes, 59 seconds in both count down and count up stopwatch modes.
- In countdown timer mode, the alarm will sound for 1 minute at the end of the cycle. Press "START/STOP" button to turn the alarm off. It will stop beeping after one minute to save battery life. Time will begin to count up when alarm sounds, so you know how much time has elapsed since time expired. If only one channel is selected and activated by depressing the Start/Stop button, its corresponding channel symbol will be shown in display. If all channels are activated with the "START/STOP" button, T1, T2, T3 and T4 will be shown. The flashing timer channel symbols indicate that the others channels are operating. Press individual timer channel button to display actual time in channel.
- The clock function is independent of the timing channels.

3. To set clock

- Press and hold "CLOCK" button for 3 seconds until the digits flash in display.
- Press "HR", "MIN", "SEC" buttons to set desired time.
- If "AM" or "PM" is displayed, the clock is on 12HR setting. To change to 24HR setting, hold the "HR" button until "AM/PM" is no longer visible.
- Press "CLOCK" button to start clock. The seconds will continue to count in the clock mode. The clock operates independently of the timer channels.

Whenever the clock button is pressed, the time of day will appear in the display. If the timers are operating, respective T1, T2, T3 or T4 will flash in the display.

4. To set count down timers

- Press "T1", "T2", "T3" or "T4" button for desired timing channel.
- Press individual "HR", "MIN", "SEC" buttons to programme desired time. The numbers can be fast forwarded by holding the individual button down for 2 seconds. If error is made in programming, press "CLEAR" button to zero the display.
- Press "START/STOP" button once to activate timer. Time will count down in seconds.
- When time expires, the alarm will sound and timer will begin to count up in seconds. Press "START/STOP" button to turn alarm off and stop count up. Each timer channel has its own distinctive alarm. Timer 1 has 1 repetitive beep, Timer 2 has 2 repetitive beeps, Timer 3 has 3 repetitive beeps and Timer 4 has 4 repetitive beeps. If not turned off, the alarm will automatically turn off in 60 seconds, however count up timer continues to operate until "START/STOP" button is pressed. Press "CLEAR" button to reset display to zero.
- Follow the same procedure above for programming the other timer channels. All timer channels can be used at the same time. When using all timer channels, simply press the channel button to note count down timer remaining. Solid channel symbol indicates the count down time of the channel being displayed. Flashing channel symbols indicate other timer channels are in operation.

5. To stop/restart or clear count down timers

- If you wish to stop timing function before time expires, press the correct timer channel button, then press "START/STOP" button once. To resume same timing period, press "START/STOP" button once again. If you wish to clear timer, press "START/STOP" button, then press "CLEAR" button to reset display to zero.

6. Memory recall

After time has expired and timer has been turned off, last count down time can be recalled by pressing the "START/STOP" button.

7. To set count up/stopwatch timer

- Press desired timer channel button then press "CLEAR" button to clear display.
- Press "START/STOP" button - timer will begin to count up in 1 second intervals.
- To stop timing process, press "START/STOP" button. To restart, press "START/STOP" again.
- To turn timer off, press "START/STOP" button then press "CLEAR" button. If count up/stopwatch timer is not turned off when it reached 99 hours, 59 minutes, 59 seconds, the digits will continue to flash until the "START/STOP" button is pressed. Press "CLEAR" button to reset the timer to zero.



Please dispose of electrical devices in accordance with local regulation.

Manufacturer: S. Brannan & Sons Ltd, Leconfield Industrial Estate, Cleator Moor, Cumbria, UK, CA25 5QE
(sales@brannan.co.uk)

EU Authorised Representative: Comply Express Unipessoal Limitada, Startup Madeira EV141,
Campus da Penteada, Funchal 9020-105, Madeira, Portugal.
(info@complyexpress.com)

brannan.co.uk

Measurement for life.

Brannan

REV2.2025