

Brannan instruction sheet

Water resistant digital test thermometer (31/162/0)

Product features:

- Stainless steel probe thermometer
- Protective case and pocket clip
- Water resistant to IP65
- Battery and full instructions included

Product specification:

Temperature range: -40 to +200°C/F

Ambient operating temp: -10 to +50°C/F

Accuracy: -40 to -21°C: +/-4°C, -20 to -1°C: +/-2°C, 0 to 100°C: +/-1°C,
101 to 150°C: +/-3°C, 151 to 200°C: +/-4°C

Resolution: 0.1°C/°F

Battery: 1 x LR44 (included)

Operating instructions

- Remove tab protecting battery before use.
 - Press ON/OFF to switch on thermometer.
 - Hold °C/°F button for 4 seconds to change units from Celsius to Fahrenheit.
 - Insert probe 50mm into substance to be tested.
 - Press HOLD to maintain temperature display.
 - Press and hold ON/OFF button for 4 seconds to switch off.
- The thermometer will switch off automatically after 10 minutes of inactivity.

Max min memory feature

- Press MAX/MIN button to display maximum temperature reached since the instrument was switched on/reset. The maximum temperature will display for 8 seconds before reverting back to the current temperature.
- Press again to display the minimum temperature reached since instrument was switched on. The minimum temperature will display for 8 seconds before reverting back to the current temperature.
- Press third time to display the current temperature.
- To reset the memory, press MAX/MIN button for 4 seconds while in max or min mode.

Caution

- Always keep the thermometer head away from direct heat or cold
- The probe is very sensitive - do not use abrasive material to clean the probe
- Do not use in a microwave or conventional oven

Changing the battery

- Remove the battery cover. Replace the battery and refit the cover securely.

Please note: The thermometers' metal probe can be submerged and left in water/liquid for an indefinite period of time. However, be aware, if left in hot liquid steam can damage the thermometer. The plastic body of the thermometer is only water resistant to IP65. This means it can withstand low pressure water jets and water spray for small lengths of time, such as rinsing the thermometer under a low pressure tap to clean it. If the plastic body of the thermometer is fully submerged into water, or subject to high pressure water jets, water ingress will occur and the thermometer will eventually stop working.



Please dispose of electrical devices in accordance with local regulation.

Manufacturer: S. Brannan & Sons Ltd, Leconfield Industrial Estate, Cleator Moor, Cumbria, UK, CA25 5QE
(sales@brannan.co.uk)

EU Authorised Representative: Comply Express Unipessoal Limitada, Startup Madeira EV141, Campus da Penteada, Funchal 9020-105, Madeira, Portugal. (info@complyexpress.com)



REV12.2026

Measurement for life.

