

Brannan instruction sheet



ELECTRONIC TEST THERMOMETER

Features:

- Wide measurement range
- Data hold function
- Celsius / Fahrenheit interchangeable units
- Max min memory
- Stainless steel probe
- Magnetic attachment
- Clear digital display
- 1m cable
- Hanging hook

Specifications:

Measurement range:	-40 to 200°C / -40 to 392°F
Ambient operating temp:	-10 to 50°C/°F
Accuracy:	+/-1°C between 0 and +100°C +/-2°C between -20 and -1°C or +101 and +150°C +/-4°C between -40 and -21°C or +151 and +200°C
Display resolution:	0.1°C/F
Sampling rate:	1 second
Battery:	1pc x AAA (supplied)
LCD dimensions:	17 x 38mm
Probe length:	100mm
Probe cable length:	1m
Product dimensions:	110 x 70 x 18.5mm

Button functions:

- ON/OFF: Turn on or off the LCD display
- HOLD: To keep the display value on the screen for easy read
- MAX/MIN: To display the maximum and minimum temperatures.
- °C/°F: To switch unit of display from Celsius to Fahrenheit

Instructions:

1. Remove protective tab from battery compartment before use.
The screen will display 888.8 then will display the temperature measurement.
2. Press [HOLD] button to keep measurement on the LCD for easy read.
3. Press [MAX/MIN] button to display the maximum or minimum temperature measurement.
4. While displaying max temperature, press and hold [MAX/MIN] button for 3 seconds to clear max memory.
Note: This will only clear the max memory.
5. While displaying min temperature, press and hold [MAX/MIN] button for 3 seconds to clear min memory.
Note: This will only clear the min memory.
6. Press [ON/OFF] button to switch off.

Note:

1. Change the battery if the display becomes dim.
2. Clean the probe immediately after each measurement to avoid cross contamination.

Manufacturer: S. Brannan & Sons Ltd, Leconfield Industrial Estate, Cleator Moor,
Cumbria, UK, CA25 5QE (sales@brannan.co.uk)

EU Authorised Representative: Comply Express Unipessoal Limitada, Startup Madeira EV141, Campus da Penteada,
Funchal 9020-105, Madeira, Portugal. (info@complyexpress.com)

brannan.co.uk

REV4.2026