

Product data sheet

✉ sales@brannan.co.uk

☎ +44 (0)1946 816600

🌐 brannan.co.uk

MILK AND COFFEE THERMOMETERS

The Milk and Coffee Thermometers incorporate green and red zones enabling fast and easy temperature reading of your milk or coffee and assists in making the perfect coffee, cappuccino, etc.

The thermometers are available in a choice of two probe lengths, 125mm or 175mm, with 3.8mm diameter, and are supplied complete with a stainless steel jug mounting probe clip. The thermometers have ice test and boil test markers at 0°C and 100°C, the purpose of which being to prove that the unit is working by checking the pointer moves across the scale.

The thermometers have a screw behind the dial face for recalibration.

Product specifications:

Temperature range:	-10 to 110°C / +20 to +220°F
Accuracy:	+/-4°C
Divisions:	1°C / 2°F
CE & RoHS/WEEE:	N/A
Hazard information (SDS):	See brannan.co.uk for information
Product materials:	Case: Stainless steel Probe: Stainless steel Jug clip: Stainless steel Scale: Aluminium

Weights & dimensions - 125mm probe thermometer

Net:	21g
Packaging: box -	14g
Gross:	56g
Packaged:	173mm x 50mm x 50mm
Unpackaged:	140mm x 45mm diameter

Weights & dimensions - 175mm probe thermometer

Net:	22g
Packaging: card -	16g
Packaging: blister -	12g
Gross:	50g
Packaged:	270mm x 122mm x 50.5mm
Unpackaged:	190mm x 45mm diameter



Description	Barcode	Product no
125mm probe thermometer	5 011405 311504	31/150/0
175mm probe thermometer	5 011405 311511	31/151/0

View me on the website

