

Product data sheet

✉ sales@brannan.co.uk

☎ +44 (0)1946 816600

🌐 brannan.co.uk

K-TYPE/J-TYPE THERMOCOUPLE THERMOMETERS WITH 4 INPUTS

A professional instrument with 4 inputs providing up to 4 simultaneous readings from J-Type or K-type thermocouples sensors. Readout in °C, °F or Kelvin. Supplied complete with carry case and basic K-type beaded wire thermocouples. Compatible with all Brannan K-Type probes.

Product Features:

- Large backlit LCD display shows any combination of T1, T2, T3, T4, T1-T2, T3-T4
- Electronic offset allows compensation of thermocouple errors to maximise overall accuracy
- K-Type and J-Type Sensors
 - MAX/MIN/AVG record
- Readout in °C, °F or Kelvin (K/J)
 - Auto power off
- Supplied with 4 beaded wire thermocouple probe (replacement thermocouple available)
- Complete with battery, full instructions and protective bag

Product specifications:

Beaded Probe Temperature Range:	-50 to 330°C&F
K-Type Temperature Range:	-200 to 1372°C&F*
J-Type Temperature Range:	-210 to 1100°C&F*
Basic Accuracy:	+/-0.15% rdg +1°C&F
Operating Conditions:	-20 to 60°C < 90%RH (non-condensing)
Storage Conditions:	-30 to 70°C < 75%RH
Resolution:	0.1°C&F
Sampling Rate:	1 per second
Response Time:	1 second
Battery:	1 x 9V (included)
CE & RoHS/WEEE:	Compliant
Hazard Information (SDS):	See www.brannan.co.uk for information
LCD Dimensions:	55 x 45mm
Product Dimensions:	Packaged: 197 x 107 x 46mm Unpackaged: 184 x 66 x 33mm
Product Gross Weight:	Packaged: 338g
Component Weights:	Meter: 221g Protective bag: 59g Box: 58g

* Requires specialist, wide range probe not included with this product.



Description	Barcode	Product no
4 Input K/J-Type Thermocouple Thermometer	5 011405 386851	38/685/0
Replacement Thermocouple Wire	-	38/698/0

View me on the website

