


Product data sheet

 sales@brannan.co.uk

 +44 (0)1946 816600

 brannan.co.uk

ASN010 - POROUS TYPE SNUBBERS FOR PRESSURE GAUGE

These contain a semi-permeable mesh disc which creates a barrier against the force of pressure, slowing it down so the gauge is protected. They are intended to suppress the effect of pressure pulses and pressure spikes. Porous type snubbers will considerably increase the service life of pressure gauges.



Product features:

- Protects gauge from pressure spikes and pulsation
- Available in brass or 304 stainless steel
- Extends life of pressure gauge
- Max working pressures: 1/4" - 100 bar
3/8" - 135 bar
1/2" - 340 bar

Standard product numbers:

Connection	Product numbers	
	Brass	304 Stainless Steel
1/4" BSP M x 1/4" BSP F	39/303/1	39/316/1
1/4" NPT M x 1/4" NPT F	39/303/0	39/316/0
3/8" BSP M x 3/8" BSP F	39/303/3	39/316/3
3/8" NPT M x 3/8" NPT F	39/303/2	39/316/2
1/2" BSP M x 1/2" BSP F	39/303/5	39/316/5
1/2" NPT M x 1/2" NPT F	39/303/4	39/316/4

View me on
the website

