

Product data sheet

✉ sales@brannan.co.uk

☎ +44 (0)1946 816600

🌐 brannan.co.uk

MILK & COFFEE FROTHING THERMOMETERS

The milk and coffee thermometers incorporate green and red zones enabling fast and easy temperature reading of your milk or coffee and assists in making the perfect coffee, cappuccino, etc.

The thermometers are available in a choice of two probe lengths, 125mm or 175mm, with probe diameter of Ø3.8mm, and are supplied complete with a stainless steel jug mounting probe clip. The thermometers have ice test and boil test markers at 0°C and 100°C, the purpose of which being to prove that the unit is working by checking the pointer moves across the scale.



Product features:

- Celcius and Fahrenheit scale with clear zones
- Recalibration screw behind dial face
- 125mm or 175mm stainless steel probe
- Ice and boil test markers
- Jug clip

Product specifications:

Temperature range:	-10 to 110°C / +20 to +220°F
Accuracy:	+/-4°C
Divisions:	1°C / 2°F
CE & RoHS/WEEE:	N/A
Hazard information (SDS):	See brannan.co.uk for information
Product materials:	Case, probe & clip: stainless steel Scale: aluminium

Milk & coffee thermometer with 125mm probe

Product dimensions:	Net: 140mm x 45mm diameter Gross: 173mm x 50mm x 50mm
Product weights:	Net: 21g Card packaging: 14g Gross: 56g

Milk & coffee thermometer with 175mm probe

Product dimensions:	Net: 190mm x 45mm diameter Gross: 192mm x 122mm x 50.5mm
Product weights:	Net: 22g Card packaging: 18g Gross: 40g

Description	Barcode	Product no
125mm probe thermometer	5 011405 311504	31/150/0
175mm probe thermometer	5 011405 311511	31/151/0

View me on the website

