

Product data sheet

✉ sales@brannan.co.uk

☎ +44 (0)1946 816600

🌐 brannan.co.uk

SPH006 - SPECIAL PURPOSE HYDROMETER - COLOSTRUM HYDROMETER

232mm long hydrometer to estimate immunoglobulins in colostrum by measuring the specific gravity of colostrum and assist with dairy/milk production. Poor quality colostrum (red band) is less than 1035. Intermediate quality colostrum (Light green band) is between 1035 and 1045. Good quality colostrum (dark green band) is higher than 1045. Also available with glass hydrometer jar. All hydrometers can be supplied with UKAS certification, certificate traceable to Recognised National Standard or Statement of Conformity, if required.

Product features:

- Coloured zones
- 232mm long
- Made in UK
- Supplied in protective, resealable plastic tube

Product specifications:

Material: Soda glass, steel shot ballast, synthetic wax resin
°SG Range: 1.025 to 1.075 °SG
Accuracy: +/- 1 °SG
Divisions: 0.1 °SG
Overall length: 232mm
Bulb diameter: 18mm
Approx weight: 35g (including 10g protective plastic tube)

Body material	Range	Product no
Colostrum Hydrometer	1.025 to 1.075°SG	10/690/0
Colostrum Hydrometer with Jar	1.025 to 1.075°SG	10/691/0



View me on
the website

