

Product data sheet

✉ sales@brannan.co.uk

☎ +44 (0)1946 816600

🌐 brannan.co.uk

HAND HELD PROGRAMMER AND DATA COLLECTOR FOR USB DATA LOGGER RANGE

This DataPad allows users of Brannan data loggers to configure their units and download data and View logging results on-the-spot rather than removing the logger from the environment being measured and taking it to their PC. This allows continual logging with shorter breaks in data collection, less travel for the user, on-site data collection in graph, legend and summary format and the ability for users to reconfigure loggers in 'the field'.



The logger is connected to the DataPad via a standard USB port at the top of the viewer. Once connected, the user is guided through a simple touchscreen menu with options to Set-Up Logger, Stop Logger and Download and View Data. On-screen instructions follow the same structure as Brannan's USB software for PC currently provided with each data logger.

Data from up to 100 loggers can be viewed on the DataPad, with data from a further 400 units stored on the DataPad at any one time. Data can be transferred to a PC or Mac using the micro USB cable supplied with the unit. Once uploaded, data is saved in comma separated variable (csv) format, making it suitable for import into spreadsheet packages such as Microsoft Excel or graphed on a PC using Brannan's software.

Product Features:

- Collects and stores data from up to 500 data loggers
- Compatible with all models from the Brannan USB Data Logger range
- View downloaded data with general trend and summary screens
- Allows full or quick set-up of compatible EasyLog USB data loggers
- Touch screen interface for navigation of menus
- 2.8" TFT display
- Stored data can be transferred to a PC/MAC via micro USB cable
- Use EasyLog USB software on a PC to graph data and export to Excel
- Integrate rechargeable lithium battery provides up to 8 hours use (nominal)



	Minimum	Typical	Maximum
Data Recording Capacity	-	>8.5 million readings	-
Operating Time	-	8 hours*	-
Operating Temperature Range	0°C/+32°F	-	+50°C/+122°F

* 5 hours constant use

Product data sheet

✉ sales@brannan.co.uk

☎ [+44 \(0\)1946 816600](tel:+44(0)1946816600)

🌐 brannan.co.uk

Product specifications:

Battery:	Lithium Polymer, rechargeable via micro-USB connection
Hardware:	240 x 320 2.8TFT LCD with touch screen Internal Flash memory Single front-panel push-button used for power-switch. Single press = ON, press & hold for 3 secs = OFF. 1 x USB Type A socket (top of unit) for connection of Brannan Data Loggers 1 x micro-USB (bottom of unit) for connection of unit to PC via 1m USB cable (supplied)
CE/ROHS/WEEE:	Compliant
Hazard Information (SDS):	See brannan.co.uk for information
Product dimensions:	Net: 107mm x 68mm x 49mm Gross: 100mm x 140mm x 40mm
Product weights:	Net: 125g (incl battery and lead) Box & Instructions (paper): 38g Insert Tray (plastic): 16g Gross: 169g

Description	Barcode	Product no
Handheld programmer and data collector for USB data logger range	5 011405 387608	38/76/0

View me on
the website

