

Brannan Product Data Sheet

PDS0094.20.REV5



Compact Psychrometer

Whirling hygrometers, also known as sling psychrometers, employ the “wet” and “dry” bulb principle to determine percentage relative humidity. They are designed to be rotated, by hand, to provide adequate and consistent ventilation of the bulbs.

The Compact Whirling Hygrometer instrument incorporates a ‘slide rule’ type calculator to determine the % RH. The body of the instrument slides away into the handle providing complete protection when not in use. Fitted with environmentally friendly LO-tox™ filled glass tubes.

Refill tubes available (see below)

Product Features:

- Slide rule type calculator to determine the %RH
- Unique, non hazardous, mercury free filling
- Fold away into case when not in use
- Made in UK

Product Specifications

Temperature Range:	-5 to +50°C or 0 to 120°F
Divisions:	0.5°C or 1.0°F
Accuracy:	+/-1
CE/ROHS/WEEE:	N/A
Hazard Information (SDS):	See www.brannan.co.uk for information
Casing Material:	ABS
Product Weight:	Packaged - 90g Unpackaged - 73g
Product Dimensions :	Packaged - 41 x 213 x 19.5mm Unpackaged (closed) - 36 x 210 x 16mm
Display Box Weight:	17g
Display Box Dimensions:	41 x 213 x 19.5mm

Description	Barcode	Product No
Celcius Compact Hygrometer	5 011405 136060	13/606/2
Replacement Tube	n/a	13/605/2
Fahrenheit Compact Hygrometer	5 011405 136060	13/606/1
Replacement Tube	n/a	13/605/1

www.brannan.co.uk

Measurement for Life.

