

# THERMcert™ range

## Product data sheet

✉ [sales@brannan.co.uk](mailto:sales@brannan.co.uk)

☎ +44 (0)1946 816600

🌐 [brannan.co.uk](http://brannan.co.uk)

### PRE-CALIBRATED MILK & COFFEE THERMOMETER

High accuracy thermometer pre-calibrated at two fixed temperature points as part of the Brannan THERMcert™ range.

The milk and coffee thermometers incorporate green and red zones enabling fast and easy temperature reading of your milk or coffee and assists in making the perfect coffee, cappuccino, etc.

The 125mm stainless steel stem has a probe diameter of Ø3.8mm, complete with a stainless steel jug mounting probe clip.

The thermometers have ice test and boil test markers at 0°C and 100°C, the purpose of which being to prove that the unit is working by checking the pointer moves across the scale.



#### Product functions:

- High accuracy thermometer supplied with traceable calibration certificate
- Celcius and Fahrenheit scale with clear zones
- Recalibration screw behind dial face
- Ice and boil test markers
- 125mm stainless steel probe with jug clip

#### Product specifications:

Temperature range:	-10 to 110°C / +20 to +220°F
Accuracy:	+/-4°C
Recommended minimum immersion length:	40-50mm*
Divisions:	1°C / 2°F
Calibration:	2 points @ 0 and 90°C
CE & RoHS/WEEE:	N/A
Hazard information (SDS):	See <a href="http://brannan.co.uk">brannan.co.uk</a> for information
Product materials:	Case, probe & clip: stainless steel Scale: aluminium
Product dimension:	Net: 140mm x 45mm diameter
Product weight:	Net: 21g

\* The thermometers will operate at shorter immersions, however the stated accuracy cannot be maintained.



Description	Calibration points	Product no
THERMcert™ pre-calibrated milk and coffee thermometer	2 fixed points at 0 and 90°C	TC-025
Recalibration product reference: TC-024-RECALIBRATION		



Measurement for life.

